## **Finishing**

CLIENT





ARTICLE N°14 MORN BASED ON WE RECIPE NO.

MATERIAL SHEEP SKIN Corrected grain 30.08.2023 DATE

COLOUR TPX 13-0403 **TECHNICIAN** Giorgio Giraudo/Klaus Birkendahl

Product	1	2	3	4	5	6	Procedure
	<del> </del>		ļ !		<u> </u>	} 	1) 1 reverse coat, (aprox 16-18 g/sq.ft) rest
EUDERM® Driver PE-C	50						overnight, vacum 50°C/ 2 min
WATER	650						
PRIMAL™ FGR	300				 !	<del> </del>	
	Ī					Ī	
PRESKIN			ļi			<u> </u>	2) preskin by reverse coat
AQUADERM® FLUID H		40	<u> </u>			<u> </u>	on release paper (2 - 3 gr.sqft)
ROSILK™ 2229 FM		15				<u> </u>	<u> </u>
RODA® Lite 07 Mix *		100					
ACRYSOL™ RM 819W		Х					3)Adhesive by reverse coat
AQUACAST® BA		900					on leather (6gr.sqft)
BAYDERM® BOTTOM DLV-N		100					
AQUADERM® XL 50		50					
Viscosity 40 sec, cup 4 mm							
ADHESIVE	<u> </u>				<u> </u> 	<u> </u> 	
AQUACAST® BA			700				
RODA® Cryl NP86			300		i	<u> </u>	
AQUADERM®Fluid H			10				
RODA® Lite 07 Mix *			100		!	<u> </u>	<u> </u>
ACRYSOL™ RM 819W			Х		ļ	<del></del>	
AQUADERM® XL 50			50		l	<del></del>	
Viscosity 30 sec, cup 4 mm					ļ		
V1300311, 30 300, 00p 1 11111						<del> </del>	
					ļ	<del> </del>	
					!	<del></del>	
						ļ	
	<del> </del>		ii		i 	<u> </u>	
						<del> </del>	
		L	ļ		i 	<u> </u>	
			ļ		ļ	ļ	
			ļ		! !	<del> </del>	_
					ļ	ļ	ļ
			ļ		ļ	<u> </u>	i
			ļi		ļ	ļ	i
			ļi		<u> </u>	ļ	i
					ļ 	ļ 	
Total	1000	1205	1160	0	0	0	
Comments:	1000	1203	1100	U	U	U	

**RELEASE PAPER: SAPPI Mokka B** 

RODA® is a registered or filed trademark, owned by or licensed to TFL in most countries.

Our application recommendations are in line with our present state of knowledge. They do not, however, exempt the customer from performing his own tests to determine the suitability of the supplied products for their intended purpose. Application of the products lies outside the scope of our control and therefore comes within the customer's sphere of responsibility. We guarantee the satisfactory quality of our products subject to our general terms of sale and delivery.